


**NEW!**  
more on  
reverse

# TV BRIDGE™ II Kits

*Pre-Wired, Pre-Assembled Box Kits for Flat Screen TV Installations*




Arlington's new non-metallic **TV Bridge™ II** box kits are the easiest, fastest way to install a flat screen TV. They include *two* boxes and the necessary connections needed to install the TV and additional components.

Installation is *faster* because we've done the advance assembly work for you! You'll get a fully assembled, recessed box, with pre-wired receptacle, device, flexible cord and cord grip.

All you need to do is cut two openings in the wall, near a power source. There's no need to cut into your framing members or run power from a panel box.

- Mounting wing screws hold the boxes secure against the wall
- Plugs and connections stay inside the recessed boxes so TV mounts flush against the wall
- No mess! – wires stay hidden behind the wall
- **TV Bridge™ II** kits in four styles...  
**TVB712BK** power/low voltage box (power side angled)  
**TVBRA2K** power/low voltage box  
**TVBRA1K** Single-gang power box  
**TVBRA3K** power/low voltage box at top, single gang at bottom

## *Pre-wired TV Bridge™ II Kits in four styles...*



Patent pending



1 Stauffer Industrial Park  
Scranton, PA 18517  
**800/233.4717**  
**Fax 570/562.0646**  
**www.aifittings.com**

# TV BRIDGE™ II Series **NEW!**

## Pre-wired, Ready-to-use Box Kits for Existing Walls

### UPPER Box installation (TVB712BK shown)



- 1 Cut Top hole in wall for the TV.  
Cut Lower hole directly below the top hole, close to an existing outlet.



- 2 Drop the pre-wired device box assembly and cable through the top hole, feeding it toward the bottom hole.




- 3 Place box in Top hole.  
Feed low voltage cables for TV through opening in box.  
Tighten mounting wing screws to secure box to wall.

(continue with Lower Box installation below)


**To complete the installation:**  
Energize TV Bridge II by plugging into power source (existing outlet) or (optional) surge protector.




### LOWER Box installation



- 1 Pull pre-wired device assembly through bottom hole.



- 2 Attach device box to trim plate with screws provided. Secure trim plate to wall with mounting wing screws. Install CED130 in 2-gang boxes. Pull cables.



- 3 Attach cover plate to trim plate with screws provided.




TVB712BK

Catalog Number	UPC/DEI/NAED Mfg. #018997	Description TV BRIDGE™ II Kit	Unit/Std Pkg
TVBRA1K	24180	w/ single-gang boxes	1
TVBRA1KGC	24182	w/ single-gang boxes - w/ ground clips for Canada	1
TVBRA2K	24181	w/ 2-gang power/low voltage box	1
TVBRA2KGC	24183	w/ 2-gang power/low voltage box - w/ ground clips for Canada	1
TVBRA3K	24195	2-gang power/low voltage upper box, single gang (lower)	1
TVBRA3KGC	24196	2-gang power/low voltage upper box, single gang (lower) - w/ ground clips for Canada	1
TVB712BK	12781	w/ 2-gang power/low voltage box (power w/ angled opening)	1
TVB712BKGC	12782	w/ 2-gang power/low voltage box (power angled) - w/ ground clips for Canada	1



**Arlington**  
1 Stauffer Industrial Park  
Scranton, PA 18517  
800/233.4717  
Fax 570/562.0646  
www.aifittings.com



TVBRA1K

TVBRA2K

TVBRA3K

Distributed by